





MECCANO

 $\begin{array}{l} \text{ODE MARKS 296521, 501113, 76, 12633, 10274, 50/13476, 569/13, 884/25, 2913, 80, 124, 336, 4174, 91637, 83171, 157149, 32822, 200639, 209733, 214061, 214062, 1289, 13316, 1818, 16737, 383/13, 5848, 50204, <math>10/12258, 22826, 18982, 20063/925, 9048, 5549, 2189, 16900, 72286, 2389, 41812, 5403, 7315, 18066, 139420, 494933-4-5-29041, 26877, 6595, 404718, 410373, 55096, 12240, 41234, 8223, 1855. \end{array}$

X SERIES OUTFIT No. I

INSTRUCTION

The first step in constructing the models shown in this folder is to build the framework. Then, before proceeding further, all the nuts and bolts should be carefully tightened up.

Where Screwed Rods are used in addition to Double Angle Strips for spacing Strips apart, the latter should be secured first to ensure correct placing of the Rods. Any moving parts, such as wheel axles, etc., should next be fitted in position, and in arranging these care should be taken to leave a little play at the ends of the

The Discs are held firmly in position on the Rods by means of a nut screwed up tightly on each side.

Pivoted joints are made by locking two nuts together on one bolt, so that the Strips, etc., are only held together loosely.

The greatest fun of all is to set the models to work by means

of the Meccano X Clockwork Motor.

The possibilities of this Outfit will be greatly increased by the addition of a No. XIA Accessory Outfit, which converts a No. XI into a No. X2 and makes possible the construction of bigger and better models.

Meccano X parts may be used in conjunction with standard Meccano parts and accessories, thus opening up an entirely new field for model-building.

Copyright by MECCANO LIMITED, LIVERPOOL, throughout the World.

7 532 80 (IP)

Rods to allow free movement.

All these Models can be made with Meccano Outfit No. XI

