



BRITISH MODEL BUILDER OUTFIT No. 1

INSTRUCTION

The first step in constructing the models shown in this folder is to build the framework, afterwards tightening up the nuts and bolts.

Where Screwed Rods are used in addition to Double Angle Strips for spacing Strips apart, the latter should be secured first to ensure correct placing of the Rods. Any moving parts, such as wheel axles, etc., should next be fitted in position, and in arranging these, care should be taken to leave a little play at the ends of the Rods to allow free movement.

The Discs are held on the Rods by a nut screwed up tightly on each side.

Pivoted joints are made by locking two nuts together on one bolt, so that the Strips, etc., are only held together loosely.

The possibilities of this Outfit will be greatly increased by the addition of a British Model Builder Accessory Outfit No. 1A, which converts a No. 1 into a No. 2, and makes possible the construction of bigger and better models.

PRICE

BRITISH MODEL BUILDER PARTS MAY BE USED IN CONJUNCTION WITH STANDARD MECCANO PARTS AND ACCESSORIES

Copyright

7/532/80 (IP)

Copyrigh

All these models can be made with British Model Builder Outfit No 1. Model No. Bl.28 Railway Inspection Trolley Fire Escape